

## GEN 2.5 LIST OF RADIO NAVIGATION AIDS

ENCODE				DECODE			
STATION NAME	FACILITY	IDENT	PURPOSE	IDENT	STATION NAME	FACILITY	PURPOSE
Abu Argub	VOR/DME	ABU	E	ABU	Abu Argub	VOR/DME	E
Amal	NDB	VA	A	AC	Misrata	NDB	A
Beda	NDB	XS	A	BNA	Benina	VOR/DME	AE
Benina	VOR/DME	BNA	AE	BNR	Benina	L	A
Benina	L	BS	A	BN	Benina	L	A
Benina	L	BNR	A	BS	Benina	L	A
Benina	L	BN	A	CW	Hamada	NDB	A
Benina	ILS	I-BNI	A	DHR	Dahra	VOR/DME	AE
Beni Walid	VOR/DME	WLD	AE	DHR	Dahra	NDB	A
Beni Walid	NDB	WLD	A	G	Tripoli	L	A
Booster	NDB	XY	A	GAD	Ghadames	VOR/DME	AE
Bu Attifel	NDB	ZT	A	GAD	Ghadames	NDB	A
Dahra	VOR/DME	DHR	AE	GAL	Gialo	NDB	A
Dahra	NDB	DHR	A	GHT	Ghat	VOR/DME	AE
Dahra	NDB	LOR	A	GHT	Ghat	NDB	A
Eddib	NDB	VG	A	GRT	Gheriat	NDB	E
El Feel	NDB		A	GN	Tobruk	NDB	A
El Sharara	NDB	ROO	A	GS	Sarir	NDB	AE
Essider	NDB	OJ	A	HON	Hon	NDB	AE
Gazala	L	PE	A	ILB	Labraq	ILS	A
Ghadames	VOR/DME	GAD	AE	IZD	Mizda	VOR/DME	E
Ghadames	NDB	GAD	A	IZD	Mizda	NDB	E
Ghararah	L	TW	A	I-BNI	Benina	ILS	A
Ghat	VOR/DME	GHT	AE	I-SBH	Sebha	ILS	A
Ghat	NDB	GHT	A	I-SIT	Sirte	ILS	A
Gheriat	NDB	GRT	E	I-IWT	Tripoli	ILS	A
Gialo	NDB	OB	A	JUF	Jufra	VOR/DME	A
Gialo	NDB	GAL	A	JFR	Jufra	NDB	D
Hamada	NDB	CW	A	KDR	Kadra	NDB	E
Hateiba	NDB	KH	A	KFR	Kufra	VOR/DME	AE
Hon	NDB	HON	AE	KFR	Kufra	NDB	A
Joday	NDB	TRO	E	KH	Hateiba	NDB	A
Jufra	NDB	JFR	D	LAB	Labraq	NDB	AE
Jufra	VOR/DME	JUF	A	LOR	Dahra	NDB	A
Kadra	NDB	KDR	E	MB	Marsa Brega	NDB	AE
Kambut	NDB	OM	A	MIS	Misrata	VOR/DME	AE
Kufra	VOR/DME	KFR	AE	MS	Misrata	NDB	A
Kufra	NDB	KFR	A	MTG	Mitiga	VOR/DME	AE
Labraq	NDB	LAB	AE	OA	Samah	NDB	A
Labraq	ILS	ILB	A	OB	Gialo	NDB	A

Notes. \*A\* denotes aerodrome use (see details in respective aerodrome section of Part 3, Aerodromes)

\*E\* denotes En route use (see details in Part 2, En-route)

\*D\* denotes decommissioned or out of service.

ENCODE				DECODE			
STATION NAME	FACILITY	IDENT	PURPOSE	IDENT	STATION NAME	FACILITY	PURPOSE
Marsa Brega	NDB	MB	AE	OJ	Essider	NDB	A
Misrata	VOR/DME	MIS	AE	OM	Kambut	NDB	A
Misrata	NDB	AC	A	OR	Waha	NDB	A
Misrata	NDB	MS	A	OV	Nafoora	NDB	A
Mitiga	VOR/DME	MTG	AE	OXY	Oxy	NDB	A
Mizda	VOR/DME	IZD	E	PE	Gazala	L	A
Mizda	NDB	IZD	E	PN	Tripoli	L	A
N 29C	NDB	STF	A	PRB	Sabah	NDB	A
Nafoora	NDB	OV	A	PRC	Zella	NDB	A
Oxy	NDB	OXY	A	RAG	Raguba	NDB	A
Raguba	NDB	RAG	A	ROO	El Sharara	NDB	A
Ras Lanuf	NDB	VR	A	RJ	Tajoura	L	A
Sabah	NDB	PRB	A	SAH	Sahil	NDB	A
Sahil	NDB	SAH	A	SEB	Sebha	VOR/DME	AE
Samah	NDB	OA	A	SEB	Sebha	NDB	A
Sarir	NDB	GS	AE	SRT	Sirte	VOR/DME	AE
Sebha	VOR/DME	SEB	AE	SRT	Sirte	NDB	A
Sebha	NDB	SEB	A	STF	N 29C	NDB	A
Sebha	ILS	I-SBH	A	TBQ	Tobruk	VOR/DME	A
Sirte	VOR/DME	SRT	AE	TPI	Tripoli	VOR/DME	AE
Sirte	NDB	SRT	A	TRO	Joday	NDB	E
Sirte	ILS	I-SIT	A	TW	Ghararah	L	A
Tagrift	NDB	VH	A	TZR	Tazerbo	NDB	E
Tajoura	L	RJ	A	UBA	Ubari	L	A
Tazerbo	NDB	TZR	E	UBR	Ubari	NDB	E
Tebesty	NDB	VO	A	VA	Amal	NDB	A
Tobruk	VOR/DME	TBQ	A	VG	Eddib	NDB	A
Tobruk	NDB	GN	A	VH	Tagrift	NDB	A
Tripoli	VOR/DME	TPI	AE	VO	Tebesty	NDB	A
Tripoli	L	G	A	VR	Ras Lanuf	NDB	A
Tripoli	L	PN	A	WLD	Beni Walid	VOR/DME	AE
Tripoli	ILS	I-IWT	A	WLD	Beni Walid	NDB	A
Ubari	NDB	UBR	E	WF	Wafa	NDB	A
Ubari	L	UBA	A	XS	Beda	NDB	A
Wafa	NDB	WF	A	XY	Booster	NDB	A
Waha	NDB	OR	A	ZAR	Zwara	NDB	AE
Zawia	VOR/DME	ZAW	E	ZAW	Zawia	VOR/DME	E
Zella	NDB	PRC	A	ZEL	Zelten	NDB	A
Zelten	NDB	ZEL	A	ZT	Bu Attifel	NDB	A
Zueitina	NDB	ZUE	A	ZUE	Zueitina	NDB	A
Zwara	NDB	ZAR	AE		El Feel	NDB	A

Notes. \*A\* denotes aerodrome use (see details in respective aerodrome section of Part 3, Aerodromes)

\*E\* denotes En route use (see details in Part 2, En-route)

\*D\* denotes decommissioned or out of service.